


Instructions for SS-ONE Controller – KODO®

- **Ports**



1. USB 5V port
Use a regular USB cable for the power. 250mA max consumption.
A cable is not supplied.
2. Connecting port in DEC mode
Not in use when the unit is used as RA controller.
3. Autoguider port
ST4-compatible port to be connected with a autoguider camera.

- **Initial Setting**

4. Dip switch
For various operational setting. All 4 switches are set at OFF as default

| | 1 (Mount) | 2 (Guide speed) | 3 (Orientation) | 4 (Tracking mode) |
|-----|-----------|-----------------|---------------------|-------------------|
| OFF | PM-SP | 2x | Northern hemisphere | RA |
| ON | PM-1 | 4x | Southern hemisphere | DEC |